

# IO-Link Device AOI Test Report

Date of Test: 9/4/24

Name of Test Engineer: Anthony Molnar

Product Description of Tested Product: CMTH-M12-IO6X2-H1141

Product Firmware Rev: 1.2.5.0

PLC used to Test Product: SoftLogix

Version of StudioLogix used to Test Product: V23

Name of AOI File Tested: Turck-CMTH-Full-V1-1.LSX

Version of AOI File Tested: 1.1

**Test Notes:**

Tested with Turck-TBEN LX-8IOL-AOI ~~REV 1.1~~  
REV 1-3

Test Passed. Yes / No

## Test Plan

CMT H

9/21/24

- ☒ Drag over IO-Link Device AOI from Catalog to Project
- ☒ Verify AOI Version matches Rev file and Revision Notes from txt file in github.
- ☒ Verify AOI Description matches txt file in github.
- ☒ Create tag instances of AOI
- ☒ Configure port of device
- ☒ Copy Common Data tag
- ☒ Download project to PLC
- ☒ Verify the Wrong or Missing Device is not on
- ☒ Disconnect Device and verify missing device is on
- ☒ Connect incorrect device and verify missing device stays on
- ☒ Reconnect correct device and verify missing devices goes off
- ☒ Add test contact to disable / enable AOI. Verify acyclic data points recover.
- ☒ Verify data points go to zero when Wrong or Missing Device detected
- ☒ Check Temperature and Humidity values. Compare to webserver.
- ☒ Check Outputs for Temperature and Humidity. Compare to webserver. Cause the outputs to change states.
- ☒ Check Operating Hours, Max Temperature, Max Humidity, Min Temperature, Min Humidity. Compare to webserver.
- ☒ Check Device Status. Force a change by causing humidity to exceed 100% (i.e. breath on sensor to raise humidity). Compare to webserver.
- ☒ Check Reset\_Max and Reset\_Min by changing value from 0 to 1. Reset\_Done should turn On when complete and Min and Max Values should reset.
- ☒ Set Display\_DegF to 1 and verify temperature values change from Celsius to Fahrenheit. Reset back to 0 and verify temperature values go back to Celsius.